

INSTALLATION GUIDE

PERFORMANCE PLASTERBOARD

Breathaplasta Smooth is ideal as a healthy skim coat applied to specialist gypsum plasterboard with the use of a primer. Breathaplasta Smooth is a quick and easy lime plaster. It's easy to use and sets within 60-90 mins.

Important notes for use on plasterboard:

- Specialist plasterboard requires a primer to be used before plastering. Examples include: moisture resistant (green), fire resistant (pink), and acoustic (blue).
- Conventional gypsum plasterboard (ivory coloured paper) does not require a primer.

Mix
Water required



Add 1 x 20kg bag of Smooth to approx. 8 litres of clean water.

Mix
Time



Mix the plaster using a paddle mix for approx. 3 minutes.

Apply
Primer



Apply a primer to prepare the surface of the plasterboard.

Apply
Two coats



Apply at least 2 coats of Smooth. Each coat should be approx. 1-2mm thick.

Set
Setting time



Setting time per coat of Smooth is approx. 60-90 minutes.

Finish
Use clean trowel



Use a trowel to polish the surface until a super smooth finish is achieved.

breathAplasta



Good
for our
buildings



Good
for our
health



Good
for our
planet

Equipment Required:

Breathaplasta Smooth, clean water, primer, hawk, trowel and plastering tools.

Surface preparation:

Primer (bonding agent) is required when plastering onto specialist plasterboards.

Recommended plaster thickness:

Approx. 4mm total thickness.

Recommended plaster application:

1. Base coat of Smooth at 1-2mm.
2. Top coat of Smooth at 1-2mm.
3. After the top coat is set, return to the plaster and use a trowel to polish the surface until a super smooth finish is achieved. Do not spray more water onto the plaster and be careful not to overwork it at this stage.

Coverage per 20kg Universal bag:

Approx. 10-12m² at 2mm thickness

Setting time per coat:

Approx. 60 - 90 minutes