INSTALLATION GUIDE PERFORMANCE PLASTERBOARD

Breathaplasta Universal is ideal as a healthy skim coat applied to specialist gypsum plasterboard with the use of a primer. Breathaplasta Universal is a quick and easy lime plaster. It's simple to use and sets within an hour.

Important notes for use on plasterboard:

- Specialist plasterboard requires a primer to be used before plastering. Examples include: moisture resistant (green), fire resistant (pink), and acoustic (blue).
- Conventional gypsum plasterboard (ivory coloured paper) does not require a primer.



Apply a primer to prepare the surface of the plasterboard.



Add 1 x 18kg bag of Breathaplasta to approx. 8 litres of clean water.





Mix the plaster using a paddle mix for approx. 3 minutes.



Apply at least 2 coats of Universal. Each coat should be at 2mm thick.





Setting time per coat of Universal is approx. 45-60 minutes.



Run a clean trowel over the surface of the plaster for a smooth finish. Use a sponge float for more textured finishes.

breath Aplasta









Equipment Required:

Breathaplasta Universal, clean water, brush or mister, hawk, trowel and plastering tools.

Surface preparation:

Primer (bonding agent) is required when plastering onto specialist plasterboards.

Recommended plaster thickness:

4mm total thickness (2 x 2mm coats).

Recommended plaster application:

- 1. Base coat of Universal 2mm.
- 2. Top coat of Universal 2mm.
- 3. For a smooth finish, moisten the surface of the plaster with a fine mist spray bottle to help polish the surface with trowel.

Coverage per 18kg Universal bag:

Approx. 5m² at 4mm thickness

Setting time per coat:

Approx. 45 - 60 minutes

